

MAGNETIC PEDESTRIAN BAND

1. DEFINITION

This device has been designed to control magnetic pedestrian access systems. It is formed by a transmitter and a magnet, the ones create a closed circuit. Once the circuit is opened it sends a signal to the control board that blocks the opening or closure of the door.

2. PROGRAMMING

1. Open the case by removing the screws at the back.
2. Place the battery.
3. Open the receiver's programming mode.
4. Press the button of the magnetic pedestrian band in the remote.
5. Reassemble the case.



LECTOR PEATONAL MAGNÉTICO

1. DEFINICIÓN

Ha sido diseñado para el control de acceso peatonal mediante sistema magnético. Está formado por un emisor y un imán, los cuales forman un circuito cerrado. Una vez que este circuito se abre manda una señal a la placa bloqueando la apertura o cierre de la puerta.

2. PROGRAMACIÓN

1. Desmontar la tapa retirando los dos tornillos posteriores.
2. Colocar la pila.
3. Abrir programación en el receptor.
4. Pulsar el botón del lector peatonal del mando.
5. Volver a ensamblar la tapa.

